

HUŚTAWKA ZUZIA

SWING ZUZIA / SCHAUKEL ZUZIA





UWAGA!!





Przed rozpoczęciem pracy należy szczegółowo zapoznać się z instrukcją.

PRZYDATNE NARZĘDZIA
















Nazwa	Szt.	Wymiar
A	2	Ø80 x 2400 mm
B	2	Ø80 x 2400 mm
C	5	Ø38 x 710 mm
D	6	Ø38 x 500 mm
E	2	Ø80 x 2400 mm
F	1	Ø100 x 2400 mm
G	2	18 x 87 x 530 mm
H	2	18 x 87 x 641 mm
I	2	18 x 87 x 641 mm
J	2	18 x 70 x 502 mm
K	1	18 x 150 x 270 mm
L	3	½Ø8 x 1160 mm
M	2	½Ø8 x 600 mm
A1	2	M10 x 200 mm
B1	1	M10 x 170 mm
C1	7	M10
D1	3	M10
E1	3	M10
F1	6	26 mm
G1	10	4,5 x 50 mm
H1	26	4,5 x 30 mm
I1	22	6,0 x 60 mm
J1	4	10 x 180 mm
K1	10	8 x 80 mm
L1	4	8 x 40 mm
M1	10	M8
N1	4	Ø100 mm
O1	2	
Nie zawarte w zestawie		
X1	6	



Montaż zjeżdżalni



4**5****G1**
6 X**6****Fig. B**

7









Fig. E

